

Installation Guide

hp StorageWorks Edge Switch 2/12

Product Version: FW v06.xx/HAFM SW v08.02.00

Second Edition (July 2004)

Part Number: AA-RURCB-TE/958-000340-001

This guide provides procedures for installing, configuring, and managing the HP StorageWorks Edge Switch 2/12.



© Copyright 2003–2004 Hewlett-Packard Development Company, L.P.

Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Hewlett-Packard. The information contained in this document is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Linux is a U.S. registered trademark of Linus Torvalds.

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

Red Hat is a registered trademark of Red Hat, Inc.

Printed in the USA.

Edge Switch 2/12 Installation Guide

Second Edition (July 2004)

Part Number: AA–RURCB–TE/958-000340-001

contents

About this Guide.	9
Overview.	10
Related Documentation	10
Conventions	11
Document conventions.	11
Text symbols	11
Equipment symbols	12
Rack stability	14
Getting help	14
HP technical support	14
HP Storage Web site	15
HP Authorized Reseller	15
1 Switch Features.	17
Edge Switch 2/12 Description	18
Field Replaceable Units (FRUs)	19
Front Panel Features.	20
Power and System Error LEDs	20
Ethernet LAN Connector.	21
Initial Machine Load/Reset Button	21
SFP Transceivers (Fibre Optic Connectors)	22
Port LEDs	22
Rear Panel Features	22
Power Supply.	23
Maintenance Port.	23
Switch Management	24
Embedded Web Server (EWS).	24
Command Line Interface	24

Operational Features	25
Error-Detection, Reporting, and Serviceability Features	25
Zoning	26
Multi-Switch Fabrics	27
Software Diagnostics	27
Optional Kits	28
2 Installing and Configuring the Edge Switch 2/12	29
Installation Options	30
Review Installation Requirements	31
Unpack and Inspect the Switch	32
Install the Edge Switch on a Desktop	33
Install the Edge Switch in a Rack	35
Rack Mount Checklist	35
Mounting Hardware	35
Brackets and Rails	35
Required Tools	36
Rack Mount Procedure	36
Mounting the Adjustable Brackets in the Rack	37
Mounting the Slide Rails on the Sides of the Switch	38
Installing the Switch in the Cabinet	39
Configure Switch Network Information	40
Changing the Switch Address	40
LAN-Connect the Switch	45
2 Using the Embedded Web Server	46
Accessing the Embedded Web Server	46
Configure Switch Ports	48
Configure Switch Identification	50
Configure Date and Time	51
Configure Switch and Fabric Parameters	52
Configure Switch Parameters	52
Configure Fabric Parameters	54
Configure Network Information	57
Configure SNMP Trap Message Recipients	59
Enable or Disable the CLI	61
Configure User Rights	62
Configure Port Binding	63

Install Feature Keys (Optional)	65
Connect Cables to Fibre Channel Ports	66
Configure Zoning	67
Configure Zones.	67
Configure Zone Sets.	71
Connect the Switch to a Fabric.	72
Managing Firmware Versions	73
A Regulatory Compliance Notices	75
Regulatory Compliance ID Numbers	76
Federal Communications Commission Notice	77
Class A Equipment.	77
Class B Equipment.	77
Declaration of Conformity for Products Marked with FCC Logo—U.S. Only.	78
Modifications	78
Network and Serial Cables.	78
IEC EMC Statement (Worldwide).	79
Spécification ATI Classe A (France).	79
Canadian Notice (Avis Canadien)	80
Class A Equipment.	80
Class B Equipment.	80
European Union Notice	81
Japanese Notice	82
Taiwanese Notice	82
Harmonics Conformance (Japan)	82
German Noise Declaration	83
Laser Safety	84
Certification and Classification Information	84
Laser Safety (Finland)	85
Declaration of Conformity	86
B Technical Specifications	87
Factory Defaults	88
Physical Dimensions.	90
Environmental Specifications.	91
Power Requirements.	92
Operating Tolerances	93

C Electrostatic Discharge	95
Precautions Against Electrostatic Discharge	96
Grounding Methods	97
Index	99
Figures	
1 Edge Switch 2/12 (front view)	19
2 Edge Switch 2/12 front panel features	20
3 Edge Switch 2/12 (rear view)	22
4 Brackets included in kit	36
5 Attaching the slide rail to the switch	39
6 New Connection dialog box	41
7 Device dialog box	42
8 Port Settings dialog box	42
9 HyperTerminal window	43
10 Disconnect Now dialog box	44
11 Save Session dialog box	44
12 Enter Network Password dialog box	47
13 Embedded Web Server interface—View window	47
14 Block or unblock a port from the Configure window	48
15 Switch page—Identification tab	50
16 Switch page—Date/Time tab	51
17 Switch page—Parameters tab	52
18 Switch page—Fabric Parameters tab	55
19 Switch page—Network tab	57
20 Network configuration changes activated	58
21 Management page—SNMP tab	59
22 Management page—CLI tab	61
23 Security page—User Rights tab	62
24 Security page—Port Binding tab	64
25 Operations page—Feature Installation tab	65
26 Zoning page—Zones tab	67
27 Zoning page—Modify Zone tab	69
28 Zoning page—Zone Set tab	71
Tables	
1 Document conventions	11

2	Edge Switch 2/12 Optional Kits.	28
3	Factory-Set Defaults.	88
4	Switch Factory-Default Values for Reset Configuration Option.	88
5	Dimensions.	90
6	Environmental Specifications	91
7	Power Requirements	92
8	Operating Tolerances	93

About this Guide

This installation guide provides information to help you:

- Install the Edge Switch 2/12.
- Perform initial configuration of the switch.

About this Guide topics include:

- [Overview](#), page 10
- [Conventions](#), page 11
- [Rack stability](#), page 14
- [Getting help](#), page 14

Overview

This book is intended for use by administrators who are experienced with the following:

- Fibre Channel technology.
- StorageWorks Fibre Channel switches by Hewlett-Packard.

Related Documentation

For a list of corresponding documentation included with this product, see the Related Documents section of the *HP StorageWorks Edge Switch Release Notes*.

For the latest information, documentation, and firmware releases, please visit the HP StorageWorks website:

<http://h18006.www1.hp.com/storage/saninfrastructure.html>

For information about Fibre Channel standards, visit the Fibre Channel Industry Association website, located at <http://www.fibrechannel.org>.

Conventions

Conventions consist of the following:

- Document conventions
- Text symbols
- Equipment symbols

Document conventions

This document follows the conventions in [Table 1](#).

Table 1: Document conventions

Convention	Element
Blue text: Figure 1	Cross-reference links
Bold	Menu items, buttons, and key, tab, and box names
<i>Italics</i>	Text emphasis and document titles in body text
Monospace font	User input, commands, code, file and directory names, and system responses (output and messages)
Monospace, italic font	Command-line and code variables
Blue underlined sans serif font text (http://www.hp.com)	Web site addresses

Text symbols

The following symbols may be found in the text of this guide. They have the following meanings:



WARNING: Text set off in this manner indicates that failure to follow directions in the warning could result in bodily harm or death.



Caution: Text set off in this manner indicates that failure to follow directions could result in damage to equipment or data.

Tip: Text in a tip provides additional help to readers by providing nonessential or optional techniques, procedures, or shortcuts.

Note: Text set off in this manner presents commentary, sidelights, or interesting points of information.

Equipment symbols

The following equipment symbols may be found on hardware for which this guide pertains. They have the following meanings:



Any enclosed surface or area of the equipment marked with these symbols indicates the presence of electrical shock hazards. Enclosed area contains no operator serviceable parts.

WARNING: To reduce the risk of personal injury from electrical shock hazards, do not open this enclosure.




Any RJ-45 receptacle marked with these symbols indicates a network interface connection.

WARNING: To reduce the risk of electrical shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.



Any surface or area of the equipment marked with these symbols indicates the presence of a hot surface or hot component. Contact with this surface could result in injury.

WARNING: To reduce the risk of personal injury from a hot component, allow the surface to cool before touching.



Power supplies or systems marked with these symbols indicate the presence of multiple sources of power.

WARNING: To reduce the risk of personal injury from electrical shock, remove all power cords to completely disconnect power from the power supplies and systems.



Any product or assembly marked with these symbols indicates that the component exceeds the recommended weight for one individual to handle safely.

WARNING: To reduce the risk of personal injury or damage to the equipment, observe local occupational health and safety requirements and guidelines for manually handling material.

Rack stability

Rack stability protects personnel and equipment.



WARNING: To reduce the risk of personal injury or damage to the equipment, be sure that:

- The leveling jacks are extended to the floor.
 - The full weight of the rack rests on the leveling jacks.
 - In single rack installations, the stabilizing feet are attached to the rack.
 - In multiple rack installations, the racks are coupled.
 - Only one rack component is extended at any time. A rack may become unstable if more than one rack component is extended for any reason.
-

Getting help

If you still have a question after reading this guide, contact an HP authorized service provider or access our web site: <http://www.hp.com>.

HP technical support

Telephone numbers for worldwide technical support are listed on the following HP web site: <http://www.hp.com/support/>. From this web site, select the country of origin.

Note: For continuous quality improvement, calls may be recorded or monitored.

Be sure to have the following information available before calling:

- Technical support registration number (if applicable)
- Product serial numbers
- Product model names and numbers
- Applicable error messages
- Operating system type and revision level
- Detailed, specific questions

HP Storage Web site

The HP web site has the latest information on this product, as well as the latest drivers. Access storage at:

<http://www.hp.com/country/us/eng/prodserv/storage.html>. From this web site, select the appropriate product or solution.

HP Authorized Reseller

For the name of your nearest HP authorized reseller:

- In the United States, call 1-800-345-1518.
- In Canada, call 1-800-263-5868.

Elsewhere, see the HP web site for locations and telephone numbers:

<http://www.hp.com>.

Switch Features

1

The HP StorageWorks Edge Switch 2/12 provides up to 12 ports of low-cost and high-performance dynamic Fibre Channel connectivity for switched fabric devices or arbitrated loop devices. This function allows low-cost, low-bandwidth workgroup (edge) devices to communicate with mainframe servers, mass storage devices, or other peripherals, and ultimately to be incorporated into an enterprise storage area network (SAN) environment.

This chapter describes the Edge Switch 2/12 and switch management through the Embedded Web Server (EWS) interface. The chapter specifically describes:

- [Edge Switch 2/12 Description](#), page 18
- [Switch Management](#), page 24
- [Operational Features](#), page 25
- [Optional Kits](#), page 28

Edge Switch 2/12 Description

The Edge Switch 2/12 provides Fibre Channel connectivity through 12 ports that operate at either 1.0625 or 2.125 gigabits per second (Gbps). Switch ports can be configured as:

- Fabric ports (**F_Port**) to provide direct connectivity for up to 12 switched fabric devices.
- Fabric loop ports (**FL_Port**) to provide arbitrated loop connectivity and fabric attachment for FC-AL devices. Each FL_Port can theoretically support the connection of 126 FC-AL devices.
- Expansion ports (**E_Port**) to provide interswitch link (ISL) connectivity to fabric directors and switches. E_Port connectivity is not standard, and must be configured through an optional feature key.
- Generic mixed port (**GX_Port**) to configure a port as a generic loop port (GL_Port). This selection is available only if enabled through an optional feature key.
- Generic port (**G_Port**) to configure a port as a generic port. This selection is available only if enabled through an optional feature key.

The switch, shown in [Figure 1](#) on page 19 provides dynamic switched connections for servers and devices, supports mainframe and open-systems interconnection (OSI) computing environments, and provides data transmission and flow control between device node ports (N_Ports) as dictated by the Fibre Channel Physical and Signaling Interface (FC-PH 4.3). Through interswitch links (ISLs), the switch can connect additional switches to form a Fibre Channel multi-switch fabric.

Administrators or operators with a browser-capable PC and an Ethernet connection monitor and manage the switch through the EWS interface. The EWS interface manages only a single switch, and provides a graphical user interface (GUI) that supports product configuration, statistics monitoring, and basic operation. The EWS interface is opened from a standard Web browser running Netscape Navigator 4.6 or later or Microsoft Internet Explorer 4.0 or later.

The switch provides connectivity for devices manufactured by multiple original equipment manufacturers (OEMs). To determine if an OEM product can communicate through connections provided by the switch, or if communication restrictions apply, refer to the supporting publications for the product or contact your HP marketing representative.




Figure 1: Edge Switch 2/12 (front view)

Field Replaceable Units (FRUs)

The switch provides a modular design that enables quick removal and replacement of FRUs, small form factor pluggable (SFP) optical transceivers. Edge Switch 2/12 FRUs are detailed in the front panel feature descriptions.

Front Panel Features

Figure 2 on page 20 shows the front panel controls, connectors, and indicators.




Figure 2: Edge Switch 2/12 front panel features

Power and System Error LEDs

The PWR LED, as shown in Figure 2, illuminates when the switch is connected to facility AC power and powered on. If the LED extinguishes, a facility power source, power cord, or power distribution failure is indicated.

The ERR LED, as shown in Figure 2, illuminates when the switch detects an event requiring immediate operator attention, such as a FRU failure. The LED remains illuminated as long as an event is active. The LED extinguishes when the Clear System Error Light function is selected from the Element Manager.

The ERR LED blinks if unit beaconing is enabled. An illuminated LED (indicating a failure) takes precedence over unit beaconing. The LED also blinks (at twice the beaconing rate) when the IML/RESET button is pressed and held for more than three seconds.

Ethernet LAN Connector

The front panel provides a 10/100 megabit per second (Mbps) RJ-45 twisted-pair connector that attaches to an Ethernet LAN to provide communication with the EWS interface or an SNMP management workstation. Two green LEDs are associated with the LAN connector. When illuminated, the left LED indicates LAN operation at 10 Mbps, and the right LED indicates LAN operation at 100 Mbps.

Initial Machine Load/Reset Button

The IML/RESET button is shown in [Figure 2](#) on page 20. When the IML/RESET button is pressed, held for three seconds, and released, the switch performs an initial machine load that reloads the firmware from FLASH memory. This operation is not disruptive to Fibre Channel traffic. If the button is held for more than three seconds, the ERR LED blinks at twice the unit beaconing rate.

When the IML/RESET button is pressed and held for ten seconds, the switch performs a reset. After three seconds, the ERR LED blinks at twice the unit beaconing rate. A reset is disruptive and resets the following:

- Microprocessor and functional logic for the control processor (CTP) card and reloads the firmware from FLASH memory.
- Ethernet LAN interface, causing the connection to the EWS interface to drop momentarily until the connection automatically recovers.
- Ports, causing all Fibre Channel connections to drop momentarily until the connections automatically recover. This causes attached devices to log out and then log back in; therefore data frames lost during switch reset must be retransmitted.

A reset should be performed only if a CTP card failure is indicated. As a precaution, the IML/RESET button is flush mounted to protect against inadvertent activation.

SFP Transceivers (Fibre Optic Connectors)

The Edge Switch 2/12 provides 12 Fibre Channel ports. A single-mode or multi-mode fiber-optic cable attaches to a port through a small form factor pluggable (SFP) transceiver. The SFP provides a duplex LC interface, and can be detached from the switch port for easy replacement. The following fiber-optic transceiver types are available:

- **Shortwave laser**—Shortwave laser SFPs provide short-distance connections (2 to 500 meters) through 50-micron or 62.5-micron multi-mode fiber.
- **Longwave laser**—Longwave laser SFPs provide long-distance connections (up to 10 kilometers) through 9-micron single-mode fiber.
- E_Port (Full-Fabric) feature key is required to use the longwave laser.

Port LEDs

Amber and green/blue LEDs to the left of each Fibre Channel port illuminate, extinguish, or blink to indicate port status and port speed.

- **Amber LED**—illuminates if the port fails.
- **Green/blue LED**—illuminates green to indicate 1.0625 Gbps port operation. Illuminates blue to indicate 2.125 Gbps port operation.

Rear Panel Features

The switch provides a power supply with internal cooling fans. [Figure 3](#) illustrates the rear of the switch.




Figure 3: Edge Switch 2/12 (rear view)

Power Supply

The switch contains one power supply with internal cooling fans. The power supply steps down and rectifies facility input power to provide 3.3 volts direct current (VDC), 5 VDC, and 12 VDC to the control processor (CTP) card. The power supply also provides input filtering, overvoltage protection, and overcurrent protection.

Three cooling fans (two integrated in the power supply) provide cooling for the power supply and CTP card, as well as redundancy for continued operation if a single fan fails.

Power supply requirements are listed in “[Technical Specifications](#)” on page 87.

Maintenance Port

The rear panel provides a 9-pin D Subminiature connector (DSUB) maintenance port, as shown in [Figure 3](#) on page 22, that provides a connection for a local terminal or dial-in connection for a remote terminal. Although the port is typically used by authorized maintenance personnel, operations personnel can use the port to configure switch network addresses.

Switch Management

The switch is managed and controlled through a customer-supplied PC platform with an Ethernet connection to the EWS interface on the switch. Using this graphical user interface (GUI), operators can quickly view switch status. The interface also allows service personnel to perform configuration tasks; view system alerts and related log information; and monitor switch status, port status, and performance. FRU status and system alert information are highly visible.

Embedded Web Server (EWS)

Administrators or operators with a browser-capable PC and an Ethernet connection monitor and manage the switch through the EWS interface. The EWS interface manages only a single switch, and provides a graphical user interface (GUI) that supports product configuration, statistics monitoring, and basic operation. The EWS interface is opened from a standard web browser running Netscape Navigator 4.6 or later or Microsoft Internet Explorer 4.0 or later.

At the browser, enter the Internet Protocol (IP) address of the switch as the Internet uniform resource locator (URL). When prompted at a login screen, enter a user name and password.

Refer to the *HP StorageWorks Embedded Web Server User Guide* for more information.

Command Line Interface

The command line interface (CLI) allows you to access many switch management functions while entering commands during a Telnet session with the switch. The primary purpose of the CLI is to automate management of a large number of switches using scripts. The CLI is not an interactive interface; no checking is done for pre-existing conditions and no prompts display to guide users through tasks.

Refer to *HP StorageWorks CLI Reference Guide for Directors and Edge Switches* for more information.

Operational Features

The Edge Switch 2/12 supports several operational features including:

- Advanced error detection, reporting, and serviceability
- Zoning
- Support for multi-switch fabrics
- Software diagnostics to aid in fault isolation and repair

Error-Detection, Reporting, and Serviceability Features

The switch provides the following error detection, reporting, and serviceability features:

- Light-emitting diodes (LEDs) on switch FRUs and adjacent to Fibre Channel ports that provide visual indicators of hardware status or malfunctions.
- FRUs (SFP transceivers) that are removed or replaced without disrupting switch or Fibre Channel link operation.
- A modular design that enables quick removal and replacement of FRUs without the use of tools or equipment.
- System alerts and logs that display switch, Ethernet link, and Fibre Channel link status at the EWS interface.
- Diagnostic software that performs power-on self-tests (POSTs) and port diagnostics (loopback tests).
- An RS-232 maintenance port at the rear of the switch (port access is password-protected) that enables installation or service personnel to change the switch's IP address, subnet mask, and gateway address.

These switch parameters can also be changed through a Telnet session, access for which is provided through a local or remote PC with an Ethernet connection to the switch.

- Data collection through the EWS interface application to help isolate system problems. The data includes a memory dump file and audit, hardware, and engineering logs.
- Beaconing to assist service personnel in locating a specific port or switch. When port beaconing is enabled, the amber LED associated with the port flashes. When unit beaconing is enabled, the system error indicator on the front panel flashes. Beaconing does not affect port or switch operation.

- SNMP management using the Fibre Channel Fabric Element MIB (Version 3.1), Transmission Control Protocol/Internet Protocol (TCP/IP) MIB-II definition (RFC 1213), or a product-specific MIB that runs on the switch. Up to six authorized management workstations for Edge switches and directors, and up to 12 on the HAFM appliance can be configured through the EWS interface and Element Manager to receive unsolicited SNMP trap messages. The trap messages indicate product operational state changes and failure conditions.

Note: For more information about SNMP support provided by Hewlett-Packard products, refer to the *HP StorageWorks SNMP Reference Guide for Directors and Edge Switches*.

Zoning

The switch supports a hardware-enforced name server zoning feature that partitions attached devices into restricted-access groups called zones. Devices in the same zone can recognize and communicate with each other through switched port-to-port connections. Devices in separate zones cannot communicate with each other.

Note: Zoning is disabled by default. You must enable zoning in order to see the attached nodes.

Zoning is configured by authorizing or restricting access to name server information associated with device N_Ports that attach to switch fabric ports (F_Ports). A zone member is specified by the port number to which a device is attached, or by the eight-byte (16-digit) World Wide Name (WWN) assigned to the host bus adapter (HBA) or Fibre Channel interface installed in a device. A device can belong to multiple zones.



Caution: If zoning is implemented by port number, a change to the switch fiber-optic cable configuration disrupts zone operation and may incorrectly include or exclude a device from a zone.

If zoning is implemented by WWN, removal and replacement of a device HBA or Fibre Channel interface (thereby changing the device WWN) disrupts zone operation and may incorrectly include or exclude a device from a zone.

In Open Fabric mode, only zoning by WWN is supported. Zoning by port numbers is not.

Zones are grouped into zone sets. A zone set is a group of zones that is enabled (activated) or disabled across all switches in a multi-switch fabric. Only one zone set can be enabled at one time.

Multi-Switch Fabrics

A Fibre Channel topology that consists of one or more interconnected switches or switch elements is called a fabric. Optional E_Port (Full-Fabric) feature key provides the ability to interconnect switches (through E_Port connections) to form a multi-switch fabric. The data transmission path through the fabric is typically determined by fabric elements and is user-transparent. Subject to zoning restrictions, devices attached to any interconnected switch can communicate with each other through the fabric.

Software Diagnostics

The switch provides the following diagnostic software features that aid in fault isolation and repair of problems:

- SFP transceivers provide on-board diagnostic and monitoring circuits that continuously report status to the EWS interface. The interface provides system alerts and logs that display failure and diagnostic information.
- The EWS interface that provides Ethernet access to isolate problems for a single switch.
- Unsolicited SNMP trap messages that indicate operational state changes or failures and can be transmitted to up to six authorized management workstations.

Optional Kits

Contact your Hewlett-Packard authorized service provider to purchase optional Edge Switch 2/12 kits. [Table 2](#) describes the Edge Switch 2/12 kits.

Table 2: Edge Switch 2/12 Optional Kits

Supporting Kit	Description
4-flexport upgrade for Edge Switch 2/12 Part Number: 348407-B21	Used to upgrade the Edge Switch 2/12 from: 4 to 8 ports 8 to 12 ports
E-Port (Full-Fabric) License for Edge Switch 2/12 Part Number: 348408-B21	Used to purchase E-Port licenses for Edge Switch 2/12 Ports.
300 m Optical Transceiver Kit Part Number: 300834-B21	Provides short-wave optical transceiver for the Edge Switch 2/12.
10 km Long-Distance Optical Transceiver Kit Part Number: 300835-B21	Provides 10 km long-wave optical transceiver for the Edge Switch 2/12.

Note: E_Port (Full-Fabric) feature key is required to use the 10 km long-distance optical transceiver.

Installing and Configuring the Edge Switch 2/12

2

This chapter describes tasks to install, configure, and verify operation of the Edge Switch 2/12. This chapter includes the following topics:

- [Installation Options](#), page 30
- [Review Installation Requirements](#), page 31
- [Unpack and Inspect the Switch](#), page 32
- [Install the Edge Switch on a Desktop](#), page 33
- [Install the Edge Switch in a Rack](#), page 35
- [Configure Switch Network Information](#), page 40
- [LAN-Connect the Switch](#), page 45
- [Using the Embedded Web Server](#), page 46
- [Configure Zoning](#), page 67
- [Connect the Switch to a Fabric](#), page 72
- [Managing Firmware Versions](#), page 73

Installation Options

The Edge Switch is installed in one of two configurations:

- **Table or desktop** — one or more Edge Switches may be installed on a desk or tabletop. Ethernet cabling, distance, and local area network (LAN) addressing issues must be considered.
- **Customer-supplied equipment rack** — one or more Edge Switches may be installed in a customer-supplied equipment rack. Rack-mount hardware is provided in the shipping container. Ethernet cabling, distance, and LAN addressing issues must be considered.

Review Installation Requirements

Verify that the following requirements are met prior to Edge Switch and EWS interface installation:

- A site plan is prepared, configuration planning tasks are complete, planning considerations are evaluated, and related planning checklists are complete, fabric and device connectivity are evaluated, and the related planning worksheet is complete. Refer to the *HP StorageWorks SAN Design Reference Guide* at:
<http://h18006.www1.hp.com/products/storageworks/san/documentation.html>.
- A browser-capable PC and Ethernet connectivity are available to support Edge Switch management through the EWS interface.
- Support equipment and personnel are available for the installation.
- The required number and type of fiber-optic jumper cables are delivered and available. Ensure the cables are the correct length with the required connectors.
- A customer-supplied equipment rack and associated hardware are available (optional).
- Remote workstations or SNMP workstations are available (optional). Workstations are customer-supplied and connected through a corporate or dedicated LAN.

Unpack and Inspect the Switch

This section provides instructions for unpacking and inspecting the Edge Switch 2/12 prior to installing it in a desktop or rack-mount configuration.

To unpack and inspect the switch:



Caution: When you remove the Edge Switch from the carton, do not rest it on its rear window while examining it. To do so may break the FRU handles.

1. Inspect the shipping containers for damage caused during transit. If a container is damaged, ensure a representative from the freight carrier is present when the container is opened.
2. Unpack the shipping containers and inspect each item for damage. Save all shipping and packing materials. Ensure that all items on the enclosed shipping list are in each container.
3. If any items are damaged or missing, contact an HP-authorized service provider or reseller.

Install the Edge Switch on a Desktop

To install and configure the Edge Switch on a desktop:

1. Remove the backing from the three adhesive rubber pads and apply the pads to the underside of the Edge Switch. Ensure the pads are aligned with the scribed circles at each corner and in the middle of the Edge Switch.
2. Position the Edge Switch on a table or desktop. Ensure that:
 - Grounded AC electrical outlets are available.
 - Adequate ventilation is present.
 - Areas with excessive heat, dust, or moisture are avoided.
 - All planning considerations are met. Refer to the *HP StorageWorks HA-Fabric Manager User Guide*.
3. Verify all field-replaceable units (FRUs), small form factor pluggable (SFP) optical transceivers, are installed as ordered.
4. Connect the U.S.- or country-specific (optional) AC power cord receptacle at the rear of the chassis.



WARNING: An HP-supplied power cord is provided for the Edge Switch power supply. To prevent electric shock when connecting the Edge Switch to primary facility power, use only the supplied power cord and ensure that the facility power receptacle is the correct type, supplies the required voltage, and is properly grounded.

5. Connect the AC power cord to a facility power source that provides single-phase, 100 to 240 volt alternating current (VAC).
When the power cord is connected, the Edge Switch powers on and performs power-on self-test (POST). During POST:
 - The green power (**PWR**) LED on the front panel illuminates.
 - The amber system error (**ERR**) LED on the front panel blinks momentarily while the Edge Switch is tested.
 - The green LEDs associated with the Ethernet port blink momentarily while the port is tested.
 - The green/blue and amber LEDs associated with Fibre Channel ports blink momentarily while the ports are tested.

6. After successful POST completion, the green power (**PWR**) LED remains ON and all other front panel LEDs turn OFF.
7. If a POST error or other malfunction occurs, refer to the *HP StorageWorks Edge Switch 2/12 Service Manual* to isolate the problem.

Install the Edge Switch in a Rack

This section describes how to mount the HP StorageWorks Edge Switch 2/12 in a standard HP rack.

Rack Mount Checklist

This section describes the contents of the rack mount kit as well as tools or equipment required to complete the installation.

Note: The hardware kit includes parts not required for the configuration described in these instructions.

Mounting Hardware

- Four (4) two-hole bar nuts
- Six (6) three-hole bar nuts (only 4 used)
- Eight (8) square alignment washers (required only for HP 9000, 10000, and 11000 series racks)
- Eight (8) Phillips panhead screws (10-32 x 1/2) with split lock and flat washers
- Eight (8) Phillips flathead screws (8-32 x 7/16)
- Ten (10) Phillips panhead screws (10-32 x 5/8) with flat washer (only 2 used)
- Six (6) Phillips flathead screws (6-32 x 3/8) (not used)
- Twelve (12) Phillips panhead screws (10-32 x 3/8) (not used)
- Four (4) 8-32 Keps nuts (not used)

Brackets and Rails

Brackets and rails included in the kit are shown in [Figure 4](#) on page 36:

- ❶ Two (2) fixed-length slide rails (one left and one right)
- ❷ Two (2) Front brackets
- ❸ Two (2) Rear brackets (long)
- ❹ Two (2) Rear spacing bracket
- ❺ Rear bracket (short)—not used in this configuration




Figure 4: Brackets included in kit

Required Tools

The following tools are required:

- Torx driver with a T10 Torx bit
- #2 Phillips screwdriver (not included in the kit)

Rack Mount Procedure

Follow this procedure to rack mount the HP StorageWorks Edge Switch 2/12 in the appropriate HP, or comparable, 19-inch Electronic Industries Association (EIA) rack:

- HP 9000 series, 10000 series, or 11000 series racks
- HP system/e or 19-inch EIA rack

Mounting the Adjustable Brackets in the Rack

Use these steps to install the adjustable brackets in the rack. You will need a #2 Phillips screwdriver and eight 10x32 panhead screws to complete this procedure.

Note: If you are installing the Edge Switch 2/12 in an HP 9000, 10000, or 11000 series rack, you will need eight square alignment washers to complete this procedure.

1. Determine the position of the switch in the rack. Each Edge Switch 2/12 is 1.75 inches or 1U high.
2. Attach four bar nuts (three-hole bar nuts) to the cabinet frame using eight Phillips panhead screws (10-32 x 1/2) with split lock and flat washers.

Note: Do not install a screw in the center hole of each bar nut.

- a. If you are installing the Edge Switch 2/12 in an HP 9000, 10000, or 11000 series rack, place a square alignment washer on each panhead screw before inserting in the square cabinet frame holes.
 - b. Mount the bar nut on the inside of the cabinet frame. Orient the holes in the bar nut so that they are aligned closest to the inside edge of the cabinet frame.
 - c. Secure, but do not completely tighten all screws.
3. Measure cabinet depth from inside edge to inside edge of the cabinet frame.
 4. Assemble two sets of front and rear brackets so that the combined brackets are equal to the depth of the cabinet.
 5. Attach a two-hole bar nut using four Phillips flathead screws (8-32 x 7/16) to hold each assembled bracket together. Do not completely tighten but tighten enough to hold the brackets together.
 6. Install the assembled brackets in the cabinet by sliding the mounting brackets between the bar nut and cabinet frame.
 7. Tighten the three-hole bar nut screws on the mounting brackets so that the rails are stable, but can be easily adjusted.
 8. Securely tighten the two-hole bar nut screws holding the front and rear brackets together.

Note: If you are installing the Edge Switch in an HP rack system/e, complete [step 9](#).

9. Attach another two-hole bar nut at the rear of the last vent slot using four Phillips flathead screws (8-32 x 7/16) to stabilize the inside ends of the rear brackets.

Mounting the Slide Rails on the Sides of the Switch

Use these steps to install the slide rails on the sides of the switch as shown in [Figure 5](#) on page 39. You will need a Torx driver with a T10 Torx bit (supplied in the kit) and left and right slide rails to complete this procedure.

1. On the Edge Switch 2/12, remove the six screws (three screws per side) that help hold the switch cover in place.

Note: Do not discard these screws, as you will use them to attach the slide rails.

2. Using the Torx driver and the screws you removed earlier, attach the left and right slide rails to the Edge Switch 2/12.




Figure 5: Attaching the slide rail to the switch

Installing the Switch in the Cabinet

Use these steps to install the switch in the cabinet. You will need a #2 Phillips screwdriver and two rear spacing brackets to complete this procedure.

1. From the front side of the cabinet, slide the switch into the mounting brackets and along the rails until the rear of the switch is flush with the rear of the cabinet.
2. Bring the rear spacing brackets to the rear of the cabinet.
3. Pull the switch toward the rear of the cabinet until it protrudes approximately 3 inches.
4. Orient the rear spacing bracket mounts so that they are pointed outward. Insert the tabs on each rear spacing bracket into the designated slots in each rail.
5. Push the switch forward using both rear spacing brackets until the rear spacing bracket mounts contact the cabinet rail.
6. Attach the rear spacing brackets to the cabinet using two Phillips panhead screws (10-32 x 5/8) with flat washer.
7. Ensuring that the square alignment washers are seated properly within the square cabinet frame holes, use a Phillips screwdriver to tighten the rear and front mounting screws.

Configure Switch Network Information

The Edge Switch 2/12 is delivered with the following default network addresses:

- **MAC address** — the media access control (MAC) address is programmed into FLASH memory on the CTP card at the time of manufacture. The MAC address is unique for each Edge Switch, and should not be changed. The address is in xx.xx.xx.xx.xx.xx format, where xx is a hexadecimal pair.
- **IP address** — the default (factory preset) internet protocol (IP) address is **10.1.1.10**.

If multiple Edge Switches are installed on the same LAN, each Edge Switch must have a unique IP address. One Edge Switch can use the factory-set address, but the addresses of the remaining Edge Switches must be changed.

- **Subnet mask** — the default subnet mask is **255.0.0.0**. If the switch is installed on a complex public LAN with one or more routers, the address may require change.
- **Gateway address** — the default gateway address is **0.0.0.0**. If the switch is installed on a dedicated LAN with no connection through a router, the address does not require change. If the switch is installed on a public LAN (corporate intranet), the gateway address must be changed to the address of the corporate intranet's local router.

Verify the type of LAN installation with the network administrator. If one switch is installed on a dedicated LAN, network addresses do not require change.

Changing the Switch Address

If multiple switches are installed or a public LAN segment is used, network addresses must be changed to conform to the LAN addressing scheme. The following items are required to perform this task.

- A local workstation (desktop or notebook computer) with the following:
 - Microsoft Windows 2000, Windows Server 2003, Windows XP, Windows 98, or Windows NT 4.0 operating system.
 - RS-232 serial communication software (for example, ProComm Plus or HyperTerminal). HyperTerminal is provided with the Windows operating systems.
- An asynchronous RS-232 null modem cable (provided with the switch).

Perform the following steps to change a switch's IP address, subnet mask, or gateway address:

1. Remove the protective cover from the 9-pin maintenance port at the rear of the switch (#2 Phillips screwdriver is required). Connect the 9-pin end of the RS-232 null modem cable to the port.
2. Connect the other cable end to a 9-pin communication port (**COM1** or **COM2**) at the rear of the maintenance terminal PC.
3. Power on the maintenance terminal. After the PC powers on, the Windows desktop displays. Refer to operating instructions shipped with the PC.

Note: Procedures for changing network addresses using the HyperTerminal serial communication software are described in [step 4](#) through [step 13](#).

4. Choose **Start > Programs > Accessories > Communications > HyperTerminal**. The New Connection dialog box displays ([Figure 6](#)).




Figure 6: New Connection dialog box

5. Enter edge switch 2-12 in the **Name** field and click **OK**. The Device dialog box displays (Figure 7).




Figure 7: Device dialog box

6. Ensure the **Connect using** field displays **COM1** or **COM2** (depending on the serial communication port connection to the switch), and click **OK**. The Port Settings dialog box displays (Figure 8).




Figure 8: Port Settings dialog box

7. Configure the **Port Settings** parameters as follows:
 - **Bits per second:** 115200
 - **Data bits:** 8
 - **Parity:** None

- **Stop bits:** 1
- **Flow control:** Hardware or None

When the parameters are set, click **OK**. The HyperTerminal window displays.

8. At the `>` prompt, enter the user-level password (the default is password). The password is case sensitive. The HyperTerminal window displays.




Figure 9: HyperTerminal window

9. At the `C>` prompt, enter `ipconfig`. The HyperTerminal window displays (Figure 9). The configuration information is listed below:

- **MAC Address**
- **IP Address** (default (factory preset) is 10.1.1.10)
- **Subnet Mask** (default is 255.0.0.0).
- **Gateway Address** (default is 0.0.0.0)

Only the **IP Address**, **Subnet Mask**, and **Gateway Address** fields are configurable.

10. If necessary, change the IP address, subnet mask, and gateway address as directed by the network administrator. To change switch network addresses, enter the following at the `C>` prompt:

```
ipconfig xxx.xxx.xxx.xxx yyy.yyy.yyy.yyy zzz.zzz.zzz.zzz
```

The IP address is always xxx.xxx.xxx.xxx, the subnet mask is always yyy.yyy.yyy.yyy, and the gateway address is always zzz.zzz.zzz.zzz. The octets xxx, yyy, and zzz are decimals from zero through 255. If the IP address will not change from the one that was set when you opened the session, then there is no need to reenter it here.

When the new network addresses are configured at the switch, the message Request completed OK displays at the bottom of the **Edge Switch 2/12 — HyperTerminal** window.

11. Choose **File > Exit** to close the HyperTerminal application. A message box displays (Figure 10).




Figure 10: Disconnect Now dialog box

12. Click **Yes**. A message box displays (Figure 11).




Figure 11: Save Session dialog box

13. Click **No** to exit and close the HyperTerminal application.
14. Power off the maintenance terminal:
 - a. Choose **Start > Shut Down**. The **Shut Down Windows** dialog box displays.
 - b. At the **Shut Down Windows** dialog box, choose **Shut down the Computer** and click **Yes** to power off the PC.
15. Disconnect the RS-232 null modem cable from the switch and the maintenance terminal. Replace the protective cover on the maintenance port.

LAN-Connect the Switch

Connect the switch to the customer-supplied Ethernet LAN segment or the Ethernet hub.

To connect the desktop or rack-mounted switch to the Ethernet LAN segment:

1. Connect one end of the Ethernet patch cable (supplied with the switch) to the RJ-45 connector (labeled **10/100**) on the left front of the chassis.
2. Connect the remaining end of the Ethernet cable to the LAN as follows:
 - If the switch is installed on a customer-supplied LAN segment, connect the cable to the LAN as directed by the network administrator.
 - If the switch is installed on an Ethernet hub, connect the cable to any available port on the hub.
3. To manage the switch through the EWS interface, attach the Ethernet LAN segment to a web browser-capable computer and go to “[Using the Embedded Web Server](#)” on page 46.

Using the Embedded Web Server

Use the EWS interface to configure the Edge Switch 2/12. Selectively perform the following configuration tasks according to your installation requirements:

- Configure switch ports.
- Configure the switch identification, date and time, switch and fabric parameters, and network addresses.
- Configure SNMP trap message recipients and enable the command line interface (CLI).
- Configure user rights and passwords.
- Install switch feature keys.

Note: This section describes the initial setup of the Edge Switch 2/12 using the EWS interface. For additional information on configuring more advanced features using EWS, see the online EWS help or the *HP StorageWorks Embedded Web Server User Guide*.

Accessing the Embedded Web Server

A PC platform with Ethernet access and a standard web browser running Netscape Navigator 4.6 or later or Microsoft Internet Explorer 4.0 or later is required.

To open the EWS interface:

1. Ensure the browser-capable PC and the Ethernet LAN segment (with the switch attached) are connected.
2. At the PC, launch the browser application (Netscape Navigator or Internet Explorer).
3. At the browser, enter the IP address of the switch as the Internet uniform resource locator (URL). Use the default (factory preset) IP address of 10.1.1.10 or the IP address configured while performing “[Configure Switch Network Information](#)” on page 40. The **Enter Network Password** dialog box displays ([Figure 12](#)).



Figure 12: Enter Network Password dialog box

4. Enter the user name and password.

Note: The default user name is *Administrator* and the default password is *password*. The user name and password are case-sensitive.

5. Click **OK**. The EWS interface opens with the View window displayed (Figure 13).




Figure 13: Embedded Web Server interface—View window

Configure Switch Ports

Perform the procedure in this section to configure names and operating characteristics for the switch ports.

To configure one or more ports:

1. Click **Configure** at the left side of the window. The **Configure** window opens with the **Ports** tab displayed (Figure 14).
 - a. For each port to be configured, type a port name of 24 alphanumeric characters or less in the associated **Name** field. The port name should identify the device to which the port is attached.
 - b. Click the check box in the **Blocked** column to block or unblock a port (default is unblocked). A check mark in the box indicates the port is blocked. Blocking a port prevents the attached device from communicating with the switch. A blocked port continuously transmits the offline sequence (OLS).




Figure 14: Block or unblock a port from the Configure window

- c. Click the check box in the **FAN** column to enable or disable the fabric address notification (FAN) feature (default is enabled). A check mark in the box indicates FAN is enabled. When the feature is enabled, the port transmits FAN frames after loop initialization to verify that FC-AL devices are still logged in. HP recommends this option be enabled for ports configured for loop operation.
 - d. Choose the port type from the **Type** drop-down list. Available selections are:
 - Generic mixed port (**GX_Port**) - Use this selection to configure a port as a generic loop port (GL_Port). This selection is available only if enabled through an optional feature key.
 - Fabric mixed port (**FX_Port**) - Use this selection to configure a port as a fabric loop port (FL_Port).
 - Generic port (**G_Port**) - This selection is available only if enabled through an optional feature key.
 - Fabric port (**F_Port**).
 - Expansion port (**E_Port**) - This selection is available only if enabled through an optional feature key.
 - e. Choose the port speed from the **Speed** drop-down list. Available selections are:
 - **Negotiate** - Auto-negotiate between 1.0625 and 2.125 gigabit per second (Gbps) operation. This is the default selection.
 - **1 Gb/sec** - 1.0625 Gbps operation.
 - **2 Gb/sec** - 2.125 Gbps operation.
2. Click **Activate** to save the information. The message “Your changes to the Port configuration have been successfully activated” displays.

Configure Switch Identification

Perform this procedure to configure the switch name, description, location, and contact person. The **Name**, **Location**, and **Contact** variables configured here correspond respectively to the SNMP variables `sysName`, `sysLocation`, and `sysContact`. These variables are used by SNMP management workstations when obtaining data from managed switches.

To configure the switch identification:

1. Choose **Configure > Switch**. The Switch page displays with **Identification** tab selected (Figure 15).

The screenshot shows a web-based configuration interface for a switch. The main title is 'Configure:'. On the right, there is a 'Refresh' button and a timestamp '12 / 6 / 02 at 10:15:38'. Below the title, there are several tabs: 'Ports', 'Switch', 'Management', 'Zoning', 'Security', and 'Performance'. The 'Switch' tab is selected. Under the 'Switch' tab, there are sub-tabs: 'Identification', 'Date / Time', 'Parameters', 'Fabric Parameters', and 'Network'. The 'Identification' sub-tab is selected. On the left side, there is a vertical menu with options: 'View', 'Configure', 'Monitor', 'Operations', and 'Help'. The 'Configure' option is highlighted. The main content area shows the 'Identification' configuration form. It has four labeled text input fields: 'Name:', 'Description:', 'Location:', and 'Contact:'. The 'Description' field contains the text 'Fibre Channel Switch'. The 'Location' and 'Contact' fields are empty and have a placeholder text '(please configure)'. Below these fields are two buttons: 'Activate' and 'Cancel'.

Figure 15: Switch page—Identification tab

- a. Enter a switch name of 24 or fewer alphanumeric characters in the **Name** field. Each switch should be configured with a unique name.

If the switch is installed on a public LAN, the name should reflect the switch's Ethernet network DNS host name. For example, if the DNS host name is `hpes224.hp.com`, then enter `hpes224`.
- b. Enter a switch description of 255 or fewer alphanumeric characters in the **Description** field.
- c. Enter the switch physical location (255 or fewer alphanumeric characters) in the **Location** field.
- d. Enter the name of a contact person (255 or fewer alphanumeric characters) in the **Contact** field.

2. Click **Activate** to save the information. The message “Your changes to the identification configuration have been successfully activated” displays.

Configure Date and Time

Perform this procedure to configure the effective date and time for the switch. To set the date and time:

1. Choose **Configure > Switch > Date/Time**. The Switch page displays with a highlighted red **Date/Time** tab selected (Figure 16).




Figure 16: Switch page—Date/Time tab

- a. Click the **Date** fields that require change, and enter numbers in the following ranges:
 Month (MM): 1 through 12
 Day (DD): 1 through 31
 Year (YY): greater than 1980
- b. Click the **Time** fields that require change, and enter numbers in the following ranges:
 Hour (HH): 0 through 23
 Minute (MM): 0 through 59
 Second (SS): 0 through 59

2. Click **Activate** to save the information. The message “Your changes to the Date/Time configuration have been successfully activated” displays.

Configure Switch and Fabric Parameters

Perform this procedure to configure the following switch and fabric operating parameters: Error Detect Time Out Value (E_D_TOV), Resource Allocation Time Out Value (R_A_TOV), preferred domain ID, and switch priority.

Configure Switch Parameters

The switch must be set offline to configure operating parameters. To configure the parameters:

1. Set the switch offline as follows:
 - a. Choose **Operations > Online State** to display the Online State tab.
 - b. Click **Set Offline**. The message “Your changes have been successfully activated” displays.
2. Click **Configure** at the left side of the panel. The **Configure** panel opens with the Ports page displayed.
3. Choose **Switch > Parameters** to display the **Parameters** tab ([Figure 17](#)).




Figure 17: Switch page—Parameters tab

4. Set the switch parameters:

- a. In **Preferred Domain ID**, enter a value between 1 and 31 (default is 1). The domain ID uniquely identifies each switch in a fabric.

All fabric-attached switches must have unique domain IDs. If the value is not unique, the E_Port connection to the switch segments and the switch cannot communicate with the fabric.

- b. Choose **Enabled** or **Disabled** from the **Insistent Domain** drop-down list. The default state is disabled. This option is not supported unless the SANtegrity feature is installed.

If insistent domain is enabled, the domain ID configured in the **Preferred Domain ID** field will become the active domain identification when the fabric initializes.

Note: If you enable **Insistent Domain** while the switch or director is online, the **Preferred Domain ID** will change to the current active domain ID if the IDs are different.

- c. Choose **Enabled** or **Disabled** from the **Rerouting Delay** drop-down list. The default state is enabled.

If rerouting delay is enabled, traffic is delayed through a fabric by the specified E_D_TOV time. This delay ensures Fibre Channel frames are delivered to their destination in order, even if a change to the fabric topology creates a new (shorter) transmission path.

- d. Choose **Enabled** or **Disabled** from the **Domain RSCNs** drop-down list. The default state is disabled.

Domain register for state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBAs) and storage devices. As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber optic cable being disconnected from a port. Consult with your HBA and storage device vendor to determine if enabling Domain RSCNs will cause problems with your HBA or storage products.

- e. Choose **Enabled** or **Disabled** from the **Suppress RSCNs on Zone set activations** drop-down list. The default state is disabled.

When the parameter is enabled, attached devices do not receive notification following any change to the fabric's active zone set.

When the parameter is disabled, attached devices (registered through the fabric format domain register) do receive notification following any change to the fabric's active zone set.

5. Click **Activate** to save the information. The message "Your changes to the Operating Parameters configuration have been successfully activated" displays.
6. Set the switch online:
 - a. Choose **Operations >Online State**. The Operations page displays with the **Online State** tab selected.
 - b. Click **Set Online**. The message "Your changes have been successfully activated" displays.

Configure Fabric Parameters

The switch must be set offline to configure fabric parameters. To configure the parameters:

1. Set the switch offline as follows:
 - a. Choose **Operations >Online State** to display the Online State tab.
 - b. Click **Set Offline**. The message "Your changes have been successfully activated" displays.
2. Click **Configure** to display the Ports page.
3. Choose **Switch >Fabric Parameters**. The Switch page displays with the **Fabric Parameters** tab selected ([Figure 18](#)).




Figure 18: Switch page—Fabric Parameters tab

4. Set the fabric parameters:

- a. At the **R_A_TOV** field, enter a value between 10 and 1200 tenths of a second (1 through 120 seconds). The default is 10 seconds (100 tenths).

All fabric-attached switches must be set to the same R_A_TOV. If the value is not compatible, the E_Port connection to the switch segments and the switch cannot communicate with the fabric. In addition, the R_A_TOV must be greater than the E_D_TOV.

- b. At the **E_D_TOV** field, enter a value between 2 and 600 tenths of a second (0.2 through 60 seconds). The default is 20 tenths of a second (2 seconds).

All fabric-attached switches must be set to the same E_D_TOV. If the value is not compatible, the E_Port connection to the switch segments and the switch cannot communicate with the fabric. In addition, the E_D_TOV must be less than the R_A_TOV.

- c. Choose **Principal**, **Never Principal**, or **Default** from the **Switch Priority** drop-down list. The default setting is **Default**.

This value designates the fabric's principal switch. The principal switch is assigned a priority of **1** and controls the allocation and distribution of domain IDs for all fabric elements (including itself).

Principal is the highest priority setting, **Default** is the next highest, and **Never Principal** is the lowest priority setting. The setting **Never Principal** means the switch is incapable of becoming a principal switch. If all switches are set to **Principal** or **Default**, the switch with the highest priority and the lowest World Wide Name (WWN) becomes the principal switch.

At least one switch in a fabric must be set as **Principal** or **Default**. If all switches are set to **Never Principal**, all interswitch links (ISLs) segment.

- d. Choose the interoperability mode from the **Interop Mode** drop-down list. Available options are:
 - **McData Fabric 1.0**—Choose this mode if the fabric contains only HP switches that are operating in Homogeneous Fabric mode.

REVIEWERS: FOR THE 2/24 AND 2/32 SWITCH, THIS OPTION IS CALLED MCDATA 1.0. DOES THAT APPLY HERE TOO?

- **Open Fabric 1.0** (default)—Choose this mode if the fabric contains HP switches, as well as other open-fabric compliant switches. Choose this mode for managing heterogeneous fabrics.
5. Click **Activate** to save the information. The message “Your changes to the Fabric Parameters configuration have been successfully activated” displays.
 6. Set the switch online:
 - a. Choose **Operations >Online State**. The Operations page displays with the **Online State** tab selected.
 - b. Click **Set Online**. The message “Your changes have been successfully activated” displays.

Configure Network Information

Verify the type of LAN installation with the network administrator. If one switch is installed on a dedicated LAN, network information (IP address, subnet mask, and gateway address) does not require change. See [“Configure Switch Ports”](#) on page 48.

If multiple switches are installed, or a public LAN segment is used, network information must be changed to conform to the LAN addressing scheme. Perform one of the following:

- If network information was changed while performing [“Configure Switch Network Information”](#) on page 40, this procedure is not required. Go to [“Configure SNMP Trap Message Recipients”](#) on page 59.
- If network information was not changed, perform the following steps to change a switch IP address, subnet mask, or gateway address:
 1. Choose **Configure > Switch > Network** to display the **Network** tab ([Figure 19](#)).




Figure 19: Switch page—Network tab

- a. At the **IP Address** field, enter the new value as specified by the network administrator (default (factory preset) is *10.1.1.10*).
- b. At the **Subnet Mask** field, enter the new value as specified by the network administrator (default is *255.0.0.0*).

- c. At the **Gateway Address** field, enter the new value as specified by the network administrator (default is *0.0.0.0*).
2. Click **Activate** to save the information. The following message box displays (Figure 20).




Figure 20: Network configuration changes activated

- d. Click **close (X)** at the upper right corner of the DOS window to close the window or enter `exit` at the prompt to return to the Windows desktop.
4. At the PC, launch the browser application (Netscape Navigator or Internet Explorer).
5. At the browser, enter the switch's new IP address as the Internet URL. The **Enter Network Password** dialog box displays.
6. Enter the user name and password.

Note: The default user name is *Administrator* and the default password is *password*. The user name and password are case-sensitive.

- Click **OK**. The EWS interface opens with the **View** window displayed.

Configure SNMP Trap Message Recipients

Perform this procedure to configure community names, write authorizations, and network addresses for up to six SNMP trap message recipients. A trap recipient is a management workstation that receives notification (through SNMP) if a switch event occurs.

To configure SNMP trap recipients:

- Choose **Configure > Management** to display the **SNMP** tab (Figure 21).

Configure: Refresh 10 / 7 / 03 at 14:40:24

Ports Switch **Management** Zoning Security Performance

SNMP CLI OSMS

☐ Enable Authentication Traps

Community Name	Write Authorization	Trap Recipient	UDP Port Number
public	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		
	<input type="checkbox"/>		

Activate Cancel

Figure 21: Management page—SNMP tab

- a. Click the **Enable Authentication Traps** check box to enable or disable transmission of SNMP trap messages to configured recipients.
 - b. For each trap recipient to be configured, type a community name of 32 alphanumeric characters or less in the associated **Community Name** field. The community name is incorporated in SNMP trap messages to ensure against unauthorized viewing or use.
 - c. Click the check box in the **Write Authorization** column to enable or disable write authorization for the trap recipient (default is disabled).

A check mark in the box indicates write authorization is enabled. When the feature is enabled, a management workstation user can change `sysContact`, `sysName`, and `sysLocation` SNMP variables which correspond respectively to the **Contact**, **Name**, and **Location** information configured under **Configure Switch Identification**.
 - d. Type the IP address or DNS host name of the trap recipient (SNMP management workstation) in the associated **Trap Recipient** field. Use 64 alphanumeric characters or less. It is recommended the IP address be used.
 - e. The default user datagram protocol (UDP) port number for trap recipients is 162. Type a decimal port number in the associated **UDP Port Number** field to override the default.
2. Click **Activate** to save the information. The message “Your changes to the SNMP configuration have been successfully activated” displays.

Enable or Disable the CLI

Perform this procedure to toggle (enable or disable) the state of the switch's command line interface:

1. Choose **Configure** > **Management** > **CLI** to display the **CLI** tab (Figure 22).




Figure 22: Management page—CLI tab

2. Perform one of the following steps as required:
 - Click **Enable** to activate the CLI. The message “Your changes to the CLI enable state have been successfully activated” displays.
 - Click **Disable** to deactivate the CLI. The message “Your changes to the CLI enable state have been successfully activated” displays.

Configure User Rights

Perform this procedure to configure the administrator-level and operator-level passwords used to access the EWS interface through the **Enter Network Password** dialog box.

To configure passwords:

1. Choose **Configure > Security** to display the **User Rights** tab (Figure 23).
2. For the **Administrator** set of data fields:
 - a. Enter the administrator user name (as specified by the network administrator) in the **New User Name** field. Use 16 or fewer alphanumeric characters.
 - b. Enter the administrator password (as specified by the network administrator) in the **New Password** field. Use 16 or fewer alphanumeric characters.
 - c. Enter the administrator password again in the **Confirm New Password** field.




Figure 23: Security page—User Rights tab

3. For the **Operator** set of data fields:
 - a. Enter the operator user name (as specified by the network administrator) in the **New User Name** field. Use 16 or fewer alphanumeric characters.
 - b. Enter the operator password (as specified by the network administrator) in the **New Password** field. Use 16 or fewer alphanumeric characters.
 - c. Enter the operator password again in the **Confirm New Password** field.
4. Click **Activate** to save the information. The message “Your changes to the User Rights configuration have been successfully activated” displays.
5. Choose **File > Close** to exit the browser
6. Log in using the new user name and password.

Configure Port Binding

Perform this procedure to configure Fibre Channel port binding by WWN:

1. Choose **Configure > Security** to display the **User Rights** tab.
2. Click **Port Binding** to display the **Port Binding** tab ([Figure 24](#)).




Figure 24: Security page—Port Binding tab

- a. Click the check box in the **Port Binding** column to enable or disable port binding for a specified port (default is disabled).
 - b. In the **Bound WWN** column, enter the WWN of the device to which the port is to be bound. If port binding is enabled, only the specified device can connect to the port. If port binding is enabled and no device is specified in the **Bound WWN** column, then no devices can connect to the port.
 - c. The **Attached WWN** column contains read-only fields that list the WWNs of attached Fibre Channel devices. Click the check box in the **Use Attached** column to indicate the WWN specified in the **Attached WWN** column is to be used for port binding. After activation, the attached WWN displays in the **Bound WWN** column.
3. Click **Activate** to save the information. The message “Your changes to the port binding configuration have been successfully activated” displays.

Install Feature Keys (Optional)

Perform this procedure to install one or more of the following optional features:

- **Flexport Technology** - A Flexport Technology switch is delivered at a discount with only four ports enabled. When additional port capacity is required, the remaining ports are enabled (in four-port increments) through purchase of this feature.
- **Full-Fabric Capability** - This feature allows Fibre Channel ports to be configured as E_Ports, G_Ports, or GX_ports.

After purchasing a feature, obtain the required feature key by following the instructions in this section. A feature key is an alphanumeric string consisting of both uppercase and lowercase characters. The total number of characters may vary. The key is case sensitive and must be entered exactly, including dashes. The following is an example of a feature key format:

XXxx-XXxX-xxXX-xX.

After obtaining the feature key, install the feature as follows:

1. Choose **Operations > Feature Installation** to display the Feature Installation page (Figure 25).



Figure 25: Operations page—Feature Installation tab

2. Enter the feature key and click **Activate**. The interface displays a confirmation page with a warning, stating that this action overrides the current set of switch features.
3. Click **Activate** to activate the new feature key. The switch performs an IPL when the key is activated.

Note: When **Activate** is selected, all current features are replaced with new features.

Note: Feature keys are encoded to work with the serial number of the installed switch only. Record the key to re-install the feature if required. If the switch fails and must be replaced, obtain new feature keys from the HP Authorization Center. Please have the serial numbers of the failed and replacement switches.

4. Go to [“Configure Switch Network Information”](#) on page 40.

Connect Cables to Fibre Channel Ports

Perform this task to connect devices to the switch:

1. Set the switch offline as follows:
 - a. Choose **Operations >Online State** to display the Online State tab.
 - b. Click **Set Offline**. The message “Your changes have been successfully activated” displays.
2. Route single-mode or multi-mode fiber-optic cables (depending on the type of SFP pluggable optic transceivers installed) from customer-specified devices to ports at the front of the switch.
3. Connect device cables to small form factor pluggable (SFP) transceivers.
4. Set the switch online as follows:
 - a. Choose **Operations >Online State**. The Operations page displays with the **Online State** tab selected.
 - b. Click **Set Online**. The message “Your changes have been successfully activated” displays.

Configure Zoning

The default zone on the Edge Switch 2/12 is disabled by default. Zoning must be configured in order for any devices connected to the edge switch to communicate. Perform this procedure to:

- Configure, change, add, or delete zones. A zone is a group of devices that can access each other through port-to-port connections. Devices in the same zone can recognize and communicate with each other; devices in different zones cannot.
- Configure, change, enable, or disable zone sets. A zone set is a group of zones that is activated or deactivated as a single entity across all managed products in either a single-switch or a multi-switch fabric. Only one zone set can be active at one time.

Configure Zones

To configure zones at the EWS interface:

1. At the **Configure** panel, choose **Zoning > Zones** to display the **Zones** tab selected (Figure 26).




Figure 26: Zoning page—Zones tab

2. To configure a zone, first add the zone name to the zoning library. The following naming conventions apply to zones and zone sets:
 - All names must be unique and may not differ by case only. For example, **zone-1** and **Zone-1** are both valid individually, but are not considered unique.
 - The first character of a zone set name must be a letter (**A** through **Z** or **a** through **z**).
 - A zone set name can have a maximum of 64 characters and cannot contain spaces.
 - Valid characters are alphanumerical and the caret (^), hyphen (-), underscore (_), or dollar (\$) symbols.
3. Enter the zone name and click **Add New Zone**. Note the following:
 - **Save and activate the zone** - Changes to a zone or zoning configuration are not saved and activated on the switch until saved as part of a zone set. Go to “[Configure Zone Sets](#)” on page 71 to perform this function.
 - **Delete all zones** - To delete all configured zones and zone members, click **Delete All Zones**. A confirmation dialog box displays. Click **OK** to delete all zones.
 - **Delete a single zone** - To delete a single zone and its zone members, click **Delete** next to the zone name. A confirmation dialog box displays. Click **OK** to delete the zone.
 - **Display more zones** - If a zone set contains more than 64 zones, the **Display More Zones** link activates to display subsequent pages. In addition, the **Display Previous Zones** link activates on subsequent displayed pages.
4. To add devices (members) to the zone, click the zone name (**Zone-1**). The Zoning page displays with the **Modify Zone** tab selected ([Figure 27](#)).




Figure 27: Zoning page—Modify Zone tab

5. Enter the new name in the **Zone** field and click **Rename Zone**. After the name is validated, the zone name is changed.
6. Add or delete zone members as follows:
 - **Add member by attached node WWN** - Select the WWN of an attached device (node) from the **Attached Node World Wide Name** drop-down list and click **Add Member**. The device is added to the zone.
 - **Add member by WWN** - Enter the WWN of an attached device in the **World Wide Name** field and click **Add Member**. The device is added to the zone.
 - **Add member by domain ID and port number** - Enter the domain ID (1 through 31) of the switch in the **Domain ID** field, enter the switch port number (0 through 11) to which a device is attached, and click **Add Member**. The device attached to that port is added to the zone.
 - **Delete a member** - To delete a zone member, click **Delete** next to the configured zone member (WWN or domain ID and port number) at the bottom of the page. A confirmation dialog box displays. Click **OK** to delete the zone member.

Note: Zoning by domain ID and port number is not available when the switch is in Open Fabric 1.0 Interop Mode.

7. Changes to a zone, zoning configuration, or zone member are not saved and activated on the switch until saved as part of a zone set. Go to “[Configure Zone Sets](#)” on page 71 to perform this function.

Configure Zone Sets

To configure zone sets at the EWS interface:

1. Click **Zoning** to display the **Zone Set** tab (Figure 28).




Figure 28: Zoning page—Zone Set tab

2. To create a zone set that incorporates zones and zone members (configured under “[Configure Zones](#)” on page 67), type a new zone set name in the **Zone Set Name** field.
3. Click **Save and Activate Zoning Configuration**. After the zone set name is validated, a confirmation dialog box displays.
4. Click **Save and Activate Zoning Configuration** to save and activate the new zone set. The message “Your Configuration changes have been successfully activated” displays. Note the following:
 - **Rename zone set** - To rename a zone set, type the new name in the **Zone Set Name** field. Click **Rename Zone Set**. The new zone set name is validated and changed.

- **Enable or disable default zone** - To toggle (enable or disable) the default zone state, click **Enable Default Zone** or **Disable Default Zone**. Depending on the toggle state, the **Default Zone** field changes to **Enabled** or **Disabled**.

Note: The default zone cannot be enabled when the switch is in Open Fabric 1.0 Interop Mode.

- **Disable zone set** - To disable the active zone set and place all attached devices in the default zone, click **Disable Zone Set**. A confirmation dialog box displays. Click **OK** to disable the active zone set.
- **Discard changes** - To discard unsaved changes made to a zone set configuration and revert to a saved zoning configuration, click **Discard Changes**. A confirmation dialog box displays. Click **OK** to discard the changes.

Connect the Switch to a Fabric

To connect the Edge Switch 2/12 to another switch in a fabric, you must have an E-port license installed in the switch to enable this feature.

To provide Fibre Channel connectivity between public devices and fabric-attached devices, connect the switch to an expansion port (E_Port) of an HP Director or Edge Switch. The switch port-to-switch port connection is called an interswitch link (ISL). To fabric-attach the Edge Switch and create an ISL:

1. Ensure the Edge Switch is accessible by the EWS interface (defined while performing “[Accessing the Embedded Web Server](#)” on page 46).
2. Ensure the preferred domain ID for the Edge Switch is unique and does not conflict with the ID of another Edge Switch participating in the fabric. To change the domain ID, see “[Configure Switch and Fabric Parameters](#)” on page 52.
3. Ensure the R_A_TOV and E_D_TOV values for the Edge Switch are identical to the values for all Edge Switches participating in the fabric. To change the values, see “[Configure Switch and Fabric Parameters](#)” on page 52.
4. Route a multi-mode or single-mode fiber-optic cable (depending on the type of SFP transceiver installed) from a customer-specified E_Port of the switch to the switch.

5. Connect the switch-attached fiber-optic cable to the port SFP transceiver.
6. Click **View** to display the **Switch** tab.
7. Click **Port Properties** to display the Port Properties page, with **0** selected, and port information listed for port 0.
8. Choose the port number of the port used to make this ISL connection.
9. Ensure the **Operational State** field displays **Online** and the **Reason** field displays **N/A** or is blank. If an ISL segmentation or other problem is indicated, refer to the *HP StorageWorks Edge Switch 2/12 Service Manual* to isolate the problem. If no problems are indicated, installation tasks are complete.

Managing Firmware Versions

The Edge Switch 2/12 internal operating code is downloaded using the EWS interface. For complete information on managing firmware, see *HP StorageWorks Edge Switch 2/12 Service Manual*.

Regulatory Compliance Notices



This appendix covers the following topics:

- [Regulatory Compliance ID Numbers](#), page 76
- [Federal Communications Commission Notice](#), page 77
- [Canadian Notice \(Avis Canadien\)](#), page 80
- [European Union Notice](#), page 81
- [Japanese Notice](#), page 82
- [Taiwanese Notice](#), page 82
- [Harmonics Conformance \(Japan\)](#), page 82
- [German Noise Declaration](#), page 83,
- [Laser Safety](#), page 84
- [Declaration of Conformity](#), page 86

Regulatory Compliance ID Numbers

For the purpose of regulatory compliance certifications and identification, your HP StorageWorks Edge Switch 2/12 is assigned a Hewlett-Packard Regulatory Model Number. The Hewlett-Packard Regulatory Model Number for this product is:

BOISA-0302

The HP StorageWorks Edge Switch 2/12 Regulatory Model Number can be found on the product label, along with the required approval markings and information. When requesting certification information for this product, always refer to this Regulatory Model Number. This Regulatory Model Number should not be confused with the marketing name or product number for your HP StorageWorks Edge Switch 2/12.

Federal Communications Commission Notice

Part 15 of the Federal Communications Commission (FCC) Rules and Regulations has established Radio Frequency (RF) emission limits to provide an interference-free radio frequency spectrum. Many electronic devices, including computers, generate RF energy incidental to their intended function and are, therefore, covered by these rules. These rules place computers and related peripheral devices into two classes, A and B, depending upon their intended installation. Class A devices are those that may reasonably be expected to be installed in a business or commercial environment. Class B devices are those that may reasonably be expected to be installed in a residential environment (for example, personal computers). The FCC requires devices in both classes to bear a label indicating the interference potential of the device as well as additional operating instructions for the user.

The rating label on the device shows the classification (A or B) of the equipment. Class B devices have an FCC logo or FCC ID on the label. Class A devices do not have an FCC logo or ID on the label. After the class of the device is determined, refer to the corresponding statement in the sections below.

Class A Equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Declaration of Conformity for Products Marked with FCC Logo—U.S. Only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding your product, refer to <http://www.hp.com>.

For questions regarding this FCC declaration, contact:

Hewlett-Packard Company
Product Regulations Manager
3000 Hanover St.
Palo Alto, CA 94304

Or call 1-650-857-1501

To identify this product, refer to the part, Regulatory Model Number, or product number found on the product.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett-Packard Company may void the user's authority to operate the equipment.

Network and Serial Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.

IEC EMC Statement (Worldwide)

This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

Spécification ATI Classe A (France)

DECLARATION D'INSTALLATION ET DE MISE EN EXPLOITATION d'un matériel de traitement de l'information (ATI), classé A en fonction des niveaux de perturbations radioélectriques émis, définis dans la norme européenne EN 55022 concernant la Compatibilité Electromagnétique.

Canadian Notice (Avis Canadien)

Class A Equipment

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Class B Equipment

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Union Notice

Products with the CE Marking comply with both the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European Norms (the equivalent international standards are in parenthesis):

- EN55022 1998 (CISPR 22)-Electromagnetic Interference
- EN55024 1998 (IEC61000-4-2, IEC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-8, IEC61000-4-11)-Electromagnetic Immunity
- EN60950 (IEC60950)-Product Safety
- Power Quality: (IEC61000-3-2)-Harmonics and (IEC61000-3-3)-Voltage Fluctuations and Flicker
- Also approved under UL 1950, 3rd Edition/CSA C22.2 No. 950-95, Safety of Information Technology Equipment

Japanese Notice

ご使用になっている装置にVCCIマークが付いていましたら、次の説明文をお読み下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

VCCIマークが付いていない場合には、次の点にご注意下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Taiwanese Notice

警告使用者：這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

Harmonics Conformance (Japan)

高調波ガイドライン適合品

German Noise Declaration

Schalldruckpegel $L_p = 59.1$ dB(A)
Am Arbeitsplatz (operator position)
Normaler Betrieb (normal operation)
Nach ISO 7779:1988 / EN 27779:1991 (Typprüfung)

Laser Safety



WARNING: To reduce the risk of exposure to hazardous radiation:

- Do not try to open the laser device enclosure. There are no user-serviceable components inside.
- Do not operate controls, make adjustments, or perform procedures to the laser device other than those specified herein.
- Allow only Hewlett-Packard authorized service technicians to repair the laser device.

Certification and Classification Information

This product contains a laser internal to the Optical Link Module (OLM) for connection to the Fibre Channel communications port.


In the USA, the OLM is certified as a Class 1 laser product conforming to the requirements contained in the Department of Health and Human Services (DHHS) regulation 21 CFR, Subchapter J. The certification is indicated by a label on the plastic OLM housing.

Outside the USA, the OLM is certified as a Class 1 laser product conforming to the requirements contained in IEC 825-1:1993 and EN 60825-1:1994, including Amendment 11:1996.

The OLM includes the following certifications:

- UL Recognized Component (USA)
- CSA Certified Component (Canada)
- TUV Certified Component (European Union)
- CB Certificate (Worldwide)

The following figure shows the Class 1 information label that displays on the metal cover of the OLM housing.



CLASS 1
LASER PRODUCT
LASER KLASSE 1

Laser Safety (Finland)

LASERTURVALLISUUS

LUOKAN 1 LASERLAITE

KLASS 1 LASER APPARAT

HP StorageWorks Edge Switch 2/12 -kytkinlaitteessa on 12 optista liitäntäporttia, joissa on laserdiodin sisältävä lähetinosa. Fibre Channel -kytkinlaite on käyttäjälle turvallinen luokan 1 laserlaite, eikä käyttäjä voi altistua turvallisuusluokan 1 ylittävälle lasersäteilylle toimiessaan käyttöohjeen mukaisesti.

Laitteen turvallisuusluokka on määritetty standardin EN 60825-1 (1994) mukaisesti.

VAROITUS ! Laitteen käyttäminen muulla kuin käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING ! Om apparaten används på annat sätt än i bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.



HP StorageWorks Edge Switch 2/12 -kytkinlaitteessa ei ole käyttäjän tehtäväksi tarkoitettuja huolto- tai säätötoimenpiteitä. Laitteen saa avata ja huoltaa ainoastaan sen huoltamiseen koulutettu henkilö.

Tiedot laitteessa käytettävän laserdiodin säteilyominaisuuksista:

Aallonpituus 850 nm

Declaration of Conformity

The Declaration of Conformity is shown below:

 DECLARATION OF CONFORMITY According to ISO/IEC Guide 22 and EN 45014	
Manufacturer's Name:	Hewlett-Packard Company
Manufacturer's Address:	11311 Chinden Blvd. Boise, ID 83714 USA
Declares, that the product	
Product Name:	hp StorageWorks edgeswitch 2/12
Product Number:	348406-B21, DS-DMGGF-BD, and ES-4300
Regulatory Model Number:	BOISA-0302
Product Options:	All
Conforms to the following Product Specifications:	
Safety:	IEC 60950:1999 / EN 60950:2000 GB 4943:1995 IEC 60825-1:1993+A1 / EN 60825-1:1994+A11, Class 1 (Laser/LED)
EMC:	CISPR 22:1997 / EN 55022:1998 Class A GB 9254:1998 CISPR 24:1997 / EN 55024:1998 IEC 61000-3-2:1995 / EN 61000-3-2:1995 + A14 IEC 61000-3-3:1994 / EN 61000-3-3:1995
Supplementary Information: The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE-marking accordingly.	
1) The Product was tested in a worst-case configuration which maximizes RFI emissions.	
Boise, ID USA September 26, 2003	 Mac McClendon, Regulatory Mgr.
<small>European contact for regulatory topics only: Hewlett-Packard GmbH, HQ-TRG, Hammerberger Strasse 140, D-71024 Böblingen (FAX: + 49-7021-14-2142)</small>	

Technical Specifications



This appendix contains the following information:

- [Factory Defaults](#), page 88
- [Physical Dimensions](#), page 90
- [Environmental Specifications](#), page 91
- [Power Requirements](#), page 92
- [Operating Tolerances](#), page 93

Factory Defaults

[Table 3](#) lists the defaults for the user name; passwords; and IP, subnet mask, and gateway addresses.

Table 3: Factory-Set Defaults

Item	Default
EWS interface username (case-sensitive)	Administrator
EWS interface password (case-sensitive)	password
Customer password	password
Maintenance password	level-2
IP address	10.1.1.10
Subnet mask	255.0.0.0
Gateway address	0.0.0.0

[Table 4](#) provides the Edge Switch factory-default values for the Reset Configuration option.

Table 4: Switch Factory-Default Values for Reset Configuration Option

Configuration	Description	Default
Identification	Switch Name	NULL string
	Switch Description	"Fibre Channel Switch"
	Switch Contact	"End User Contact (please configure)"
	Switch Location	"End User Contact (please configure)"
Ports	Port Names	NULL strings
	Port Blocked States	Unblocked
	FAN	Enabled
	Ports enabled	4
Switch Addressing	IP Address	10.1.1.10
	Subnet Mask	255.0.0.0
	Gateway Address	0.0.0.0
	MAC Address	PROM value

Table 4: Switch Factory-Default Values for Reset Configuration Option (Continued)

Configuration	Description	Default
Operating Mode	Must select one of two modes: Homogeneous mode or Open Fabric 1.0. The recommended mode is Open Fabric 1.0.	Open Fabric 1.0 mode
Operating Parameters	Preferred Domain ID	1
	Insistent Domain ID	Disabled
	Rerouting Delay	Enabled
	Domain RSCN's	Disabled
	Suppress RSCN's on Zone set activations	Disabled
	R_A_TOV	10 seconds (100 tenths)
	E_D_TOV	2 seconds (20 tenths)
	Switch Priority	Default
SNMP	SNMP Communities	"public" — 5 NULL strings
	SNMP Write Authorizations	Read only per community
	Trap Recipient IP Addressees	0 for each
	UDP Port	162
	SNMP Authorization Trap State	disabled
Zoning	Number of Zone Members	0
	Number of Zones	0
	Number of Zone Sets	0
	Zone Names	None
	Zone Sets Names	None
	Zone Members	None
	Default Zone State	Disabled
	Active Zone Set State	Disabled
	Active Zone Set Name	NULL string

Physical Dimensions

[Table 5](#) lists Edge Switch 2/12 dimensions.

Table 5: Dimensions

Dimension	Size
Height	4.4 cm (1.8 in)
Width	43.2 cm (17 in)
Depth	44.5 cm (17.5 in)
Weight	6.8 kg (15 lb)
Shipping Weight	9.5 kg (21 lb)

Environmental Specifications

[Table 6](#) lists environmental ranges for shipping, storing, and operating the HP StorageWorks Edge Switch 2/12.

Table 6: Environmental Specifications

Specification	Shipping	Storage	Operating
Weight	9.5 kg (21 lb)	7.7 kg (17 lb)	7.7 kg (17 lb)
Temperature	-40° F to 140° F (-40° C to 60° C)	34° F to 140° F (1° C to 60° C)	40°F to 104°F (4°C to 40 °C)
Humidity	5% to 100%	5% to 80%	8% to 80%
Maximum wet-bulb temperature	84° F (29° C)	84°F (29°C)	81°F (27°C)
Altitude	40,000 ft (12,192 m)	40,000 ft (12,192 m)	10,000 ft (3,048 m)

Power Requirements

[Table 7](#) lists Edge Switch 2/12 power requirements.

Table 7: Power Requirements

Specification	Value
Input voltage	100 to 240 VAC
Input frequency	47 to 63 Hz


Operating Tolerances

Table 8 lists heating and cooling specifications, shock tolerances, vibration, acoustical noise, and inclination.

Table 8: Operating Tolerances

Specification	Value
Heat dissipation	49 watts (167 BTU/hr)
Cooling airflow clearances	Right and left sides: 1.3 cm (0.5 inches) Front and rear: 7.6 cm (3.0 in) Top and bottom: No clearance required
Shock and vibration tolerance	60 Gs for 10 milliseconds without nonrecoverable errors
Acoustical noise	70 dB "A" scale
Inclination	10° maximum

Electrostatic Discharge



This appendix contains the following information.

- [Precautions Against Electrostatic Discharge](#), page 96
- [Grounding Methods](#), page 97

Precautions Against Electrostatic Discharge

To prevent damaging the system, be aware of the precautions you need to follow when setting up the system or handling parts. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

To prevent electrostatic damage, observe the following precautions:

- Avoid hand contact by transporting and storing products in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free workstations.
- Place parts on a grounded surface before removing them from their containers.
- Avoid touching pins, leads, or circuitry.
- Always make sure you are properly grounded when touching a static-sensitive component or assembly.

Grounding Methods

There are several methods for grounding. Use one or more of the following methods when handling or installing electrostatic-sensitive parts:

- Use a wrist strap connected by a ground cord to a grounded workstation or computer chassis. Wrist straps are flexible straps with a minimum of 1 megohm \pm 10 percent resistance in the ground cords. To provide proper ground, wear the strap snug against the skin.
- Use heel straps, toe straps, or boot straps at standing workstations. Wear the straps on both feet when standing on conductive floors or dissipating floor mats.
- Use conductive field service tools.
- Use a portable field service kit with a folding static-dissipating work mat.

If you do not have any of the suggested equipment for proper grounding, have an HP authorized reseller install the part.

Note: For more information on static electricity, or for assistance with product installation, contact your HP authorized reseller.

A

active zone set state, default value [89](#)
addresses, default values [88](#)
authorized reseller, HP [15](#)

B

binding, port [63](#)
brackets
 mounting [37](#)
 rails [35](#)

C

cables, FCC compliance statement [78](#)
Canadian Notice (Avis Canadien) [80](#)
CE marking [81](#)
command line interface (CLI)
 description [24](#)
 enable or disable using EWS [61](#)
configure
 feature key [65](#)
 port binding [63](#)
 SNMP trap message recipients [59](#)
 zone sets [67](#)
 zones [67](#)
 zoning (optional) [67](#)
conventions
 document [11](#)
 equipment symbols [12](#)
 text symbols [11](#)

D

declaration of conformity [78](#)

default values [89](#)
 addresses [88](#)
 identification [88](#)
 IP address [88](#)
 MAC addresses [88](#)
 operating parameters [89](#)
 ports [88](#)
 SNMP [89](#)
 zoning [89](#)
defaults
 zone states [89](#)
diagnostics [27](#)
director, connecting switch to [72](#)
document
 conventions [11](#)
 prerequisites [10](#)
 related documentation [10](#)
domain RSCN [89](#)

E

e_d_tov, default value [89](#)
E_Port
 description [18](#)
 enable through feature key [65](#)
electrostatic discharge precautions [96](#)
embedded web server *See* EWS
equipment symbols [12](#)
error detection [25](#)
European Union notice [81](#)
EWS
 configuring
 date and time [51](#), [52](#)
 network information [57](#)

- SNMP trap message recipients [59](#)
- switch identification [50](#)
- switch ports [48](#)
- user rights [62](#)
- description [24](#)

F

- F_Port, description [18](#)
- fabrics [27](#)
- FCC
 - class A compliance notice [77](#)
 - class B compliance notice [77](#)
 - compliance statement, cables [78](#)
- feature keys
 - configure [65](#)
 - Flexport Technology feature [65](#)
 - full-fabric capability [65](#)
- Federal Communications Commission (FCC)
 - notice [77](#)
- Fibre Channel ports [22](#)
- FL_Port, description [18](#)
- Flexport Technology feature key [65](#)
- front panel features [20](#)
- FRUs [22](#)
 - power supply [23](#)
 - SFP transceivers [22](#)
- full-fabric capability feature key [65](#)

G

- G_Port, description [18](#)
- gateway address
 - configuring [40](#)
 - default [88](#)
- getting help [14](#)
- grounding methods [97](#)
- GX_Port, description [18](#)

H

- hardware, mounting [35](#)
- help, obtaining [14](#)

HP

- authorized reseller [15](#)
- storage web site [15](#)
- technical support [14](#)

I

- identification, default values [88](#)
- Initial Machine Load (IML) button [21](#)
- insistent domain ID, default value [89](#)
- installation tasks
 - cabling Fibre Channel ports [66](#)
 - configuring network addresses [40](#)
 - connecting switch to fabric director [72](#)
 - LAN-connecting the switch [45](#)
 - options [30](#)
 - unpacking and inspecting switch [32](#)
 - verify installation requirements [31](#)
- interop mode
 - McData fabric 1.0 [56](#)
 - open fabric 1.0 [56](#)
- interswitch link, description [18](#)
- IP address
 - configuring [40](#)
 - default [88](#)
 - default value [88](#)

K

- kits, optional [28](#)

L

- LAN
 - connecting the switch [45](#)
 - connector [21](#)
- laser
 - devices [84](#)
 - information [86](#)
- LEDs
 - port [22](#)
 - PWR LED [20](#)
 - System Error LED [20](#)

M

- MAC addresses
 - default 88
 - defined 40
- maintenance port 23
- managing the switch 24
- McData fabric 1.0, interop mode 56
- media access control addresses *See* MAC addresses
- mounting
 - brackets 37
 - hardware 35
 - rails 37
- multi-switch fabric 27

N

- network
 - addresses, configuring 40
 - information, configuring from EWS 57

O

- Open fabric 1.0, interop mode 56
- operating parameters, default values 89
- options, kits 28

P

- password, default 88
- port binding
 - configure 63
 - description 63
- port blocked states, default value 88
- ports
 - cabling 66
 - default values 88
 - Fibre Channel 22
 - LEDs 22
 - UDP, default value 89
- power
 - requirements 92
 - supply 23
- precautions against electrostatic discharge 96

- preferred domain ID, default value 89
- prerequisites 10
- priority, default value 89

R

- r_a_tov, default value 89
- rack stability, warning 14
- rack types 36
- rails
 - in kit 35
 - mounting 37
- rear panel features 22
- Regulatory Compliance identification numbers 76
- regulatory compliance notices 75
- related documentation 10
- reporting 25
- routing delay, default value 89

S

- serviceability 25
- SFP transceivers 22
 - longwave 22
 - shortwave 22
- slide rails, mounting 37
- SNMP
 - authorization trap states, default value 89
 - communities, default value 89
 - configuring trap message recipients, EWS 59
 - default values 89
 - write authorizations, default value 89
- software, diagnostic features 27
- subnet mask
 - configuring 40
 - default 88
- suppress RSCNs on zone set activations
 - default value 89
- switch
 - connecting to fabric director 72
 - connectors and indicators 20
 - installing in cabinet 39
 - LAN connecting 45

- LEDs [20](#)
- maintenance port [23](#)
- management [24](#)
 - CLI [24](#)
 - EWS [24](#)
- multi-switch fabric [27](#)
- network addresses [40](#)
- power supply [23](#)
- SFP transceivers [22](#)
- unpacking and inspecting [32](#)
- symbols
 - in text [11](#)
 - on equipment [12](#)

T

- technical support, HP [14](#)
- text symbols [11](#)
- tools required [36](#)
- trap recipient IP addresses, default value [89](#)

U

- UDP port, default value [89](#)

- user rights, configuring, EWS [62](#)

W

- warning
 - rack stability [14](#)
 - symbols on equipment [12](#)

Z

- zone sets
 - configure [71](#)
 - default value [89](#)
 - description [67](#)
 - description of [27](#)
- zones [26](#)
 - add or delete members [69](#)
 - configure [67](#)
 - description [67](#)
 - members, default value [89](#)
 - number of, default value [89](#)
 - set state, default value [89](#)
 - states, default value [89](#)
- zoning, default values [89](#)